

OPTIMUS®

Cat. No. 33-1056

NOVA® 57 STEREO HEADPHONES

Your Optimus Nova® 57 Stereo Headphones deliver full frequency coverage in a lightweight design. These headphones are ideal for use with your home stereo system. The dual volume controls let you set the sound level on each earcup individually. The adjustable headband fits any head size or shape. The frequency response is 20–18,000 Hz. Total harmonic distortion is less than 0.5% at 105 dB SPL at 1 kHz.

High Energy Elements — deliver professional quality sound in a lightweight package.

Closed Earcup Design with Soft Foam-Filled Cushions — reduce ambient sound and provide a comfortable listening experience.

Coiled Cord with 1/8-Inch Plug and 1/8-Inch-to-1/4-Inch Plug Adapter — provides convenience and flexibility of movement.

OPTIONAL ACCESSORIES

1/4-Inch Stereo-to-Mono Adapter (Cat. No. 274-360) — lets you connect stereo headphones to any monaural source such as a CB or shortwave radio.

24-Foot 1/4-Inch Stereo Coiled Headphone Extension Cord (Cat. No. 42-2443) — lets you move about comfortably while listening.

1/4-Inch Stereo Headphone Y-Adapter (Cat. No. 42-2448) — lets you connect two pair of stereo headphones to one stereo headphone jack.

OPERATION

Caution: Turn down the volume on your sound source before plugging in the headphones.

1. Rotate the volume control on the left earcup fully clockwise, then rotate the control on the right earcup fully counterclockwise.

illus

2. Plug the headphones into a 1/4-inch stereo headphone jack. To plug the headphones into a 1/8-inch jack, remove the adapter from the plug.
3. Put on the headphones, then adjust the headband for a comfortable fit.

illus

4. Adjust the sound source's volume to between its middle and maximum level. Then adjust the volume control on each earcup to a comfortable level.

© 1997 Tandy Corporation.
All Rights Reserved.

Optimus, Nova, and RadioShack are registered trademarks used by Tandy Corporation.

Listening Safely

To protect your hearing, follow these guidelines when you use headphones.

- Set the volume to the lowest setting before you begin listening. After you begin listening, adjust the volume to a comfortable level.
- Do not listen at extremely high volume levels. Extended high-volume listening can lead to permanent hearing loss.
- Once you set the volume, do not increase it. Over time, your ears adapt to the volume level, so a

volume level that does not cause discomfort might still damage your hearing.

Traffic Safety

Do not wear headphones while operating a motor vehicle or riding a bicycle. This can create a traffic hazard and could be illegal in some areas.

Even though some headphones are designed to let you hear some outside sounds when listening at normal volume levels, they still can present a traffic hazard.

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.



This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. RadioShack Customer Relations, Dept. W, 100 Throckmorton St., Suite 600, Fort Worth, TX 76102

We Service What We Sell

3/97


RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102





RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

4A7

Printed in Hong Kong





RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

4A7

Printed in Hong Kong

